

EverBrite

RETRO RECHARGEABLE CAMPING LANTERN



TENT




KNAPSACK



CAMP



PARTY



PRODUCT PARAMETER

- This data is based on the premise of using full power.

Name	camping lamp	Charging input	5V 1.0A
Model	E041037A / E041038A / E041039A	Max power	6W
Light source	lamp bead & filament	Charging time	5.5h
Brightness	400LM	Duration	6h-48h
Battery	4400mAh	Weight	500g

FUNCTION DESCRIPTION

- Turn the knob clockwise to make an "click" sound (the filament is on).
- When the knob is twisted to the middle of the knob, the filament goes out and the top led light turns on.
- Continue to rotate clockwise according to the knob From low light to high light (two glow modes, how to highlight).

- Turn off the lights(turn the knob counterclockwise until there is an "click" sound and all the lights go out)

PRECAUTIONS LIST

Number	Name	Quantity	Description
1	Specification	1	User instruction manual
2	Camping lamp	1	A camping lamp
3	Charging cable	1	Type C interface charging cable

How to use:

- Please refer to functional operation for switching light mode.
- Don not use this lantern at extremely cold below (10℃ below zero) or hot (above 50℃) environments.
- This lantern can only meet the waterproof level of IP22, do not use it while diving; otherwise circuit failure may occur due to Water seepage.

Power

- Only the original built-in lithium battery is applicable to this lantern.Do not remove and replace the original one.
- Please use high-quality power sockets and standard USB cables to charge the lantern.
- Do not charge the lantern while it's on.

Maintainance

Do not rub the lampshade with other hard objects. If worn, it will affect the light transmission.

Common faults

- If the lantern fails to function well after charging, please:
- Try the switch button several times.
- Check if there is water seepage, and switch on the lantern again after airing it.



Notices!

- Please read through the instructions before using the lantern to learn its proper use and maintenance.
- Children shall be supervised and guided by adults while using the lantern.
- Please do not disassemble the lantern
- Please do not adapt the lantern.

Distributed by:
Hangzhou GreatStar Industrial Co., Ltd.
No.35 Jiuhuan Road, Jiubao Town, Hangzhou 310019, China
<http://www.everbrite-lighting.com>
MADE IN CHINA